

CUSTOMER MAINTENANCE & CARE GUIDELINES

Strand Woven & Engineered Bamboo Flooring

Proper maintenance is necessary and a vital requirement to maximise the performance and enjoyment of your flooring investment. A well maintained floor will provide many years of service life and will add to the overall warmth and charm that only a natural flooring product can provide.

If you follow these industry acknowledged guidelines the task of maintaining your flooring will become a regular function in the overall upkeep of the property. If you're unsure regarding any of these steps please consult with your flooring retailer to assist with your inquiry.

General maintenance; how to care for your pre-finished floor.

- Sweep floor regularly with an electrostatic broom, soft bristled broom or wood floor mop.
- Dust and or clean with a soft bristled vacuum head. Ensure vacuum head is non-abrasive with no metal contact points.
- Remove spills promptly with an absorbent cloth or similar.
- **Natural materials such as bamboo are photosensitive and will change colour as the floor ages and is exposed to ultraviolet (UV) light. This is a naturally occurring phenomenon and as such these changes are not covered by the product warranty.**
- **For new installations avoid placing rugs or mats on the floor surface for at least 2 months. This should enable a more even UV exposure to natural and internal lighting. Avoid animal rugs unless you determine the backing is PH neutral or place carpet / rug lining under to avoid bleaching the floor surface.**
- Place mats at exterior and interior doors to trap sand and grit from incoming traffic and for drying feet if pool activity is nearby.
- Use a rug or matt in high traffic areas to reduce wear & scuffing.
- Where possible periodically relocate rugs or large items to allow natural aging of the floor surface area. **For new floors please refer rug and mat details noted above.**
- Stick soft pads to the base of all furnishings in contact with the floor.
- When moving heavy furniture or appliances always pick it up rather than sliding it across the floor.
- Keep pets' claws properly trimmed to avoid excess scratches and gouges.
- If necessary, clean with a well rung out mop with warm water and a **PH neutral floor cleaner**. We strongly recommend BONA or LOBA floor care solutions; these are available from reputable flooring retailers. Consult instructions before use. **Do not use supermarket floor or general cleaning solutions as they are likely to be concentrated and if used incorrectly will damage the surface coating.**
- Your floor is pre-finished with a water-based coating suitable for residential use. If coating repairs or future re-coating is required please contact a coating professional. Small repairs are possible to the surface coating however it is vital that a test sample with a compatible brand of water-based coating is done prior to attempting the final in-situ repair. If a left over floor sample is not available attempt a small test area in a cupboard or less visible location within the room.

Prevention maintenance.

- **Do not steam mop or wet mop floor surface area after installation.** Too much water may cause the planks to swell and warp and damage the surface coating.
- **Do not use waxes or common household supermarket cleaners or detergents on the floor.** These types of cleaning solutions are very abrasive. Long term use will dull the finish and soften the surface coating reducing its durability and sheen level.
- Chairs with roller wheels must be placed on protective mats to protect the surface coating.
- Do not let sand, dirt or grit build up on the floor surface.
- Avoid walking in narrow point or stiletto heel shoes as they may damage the surface of your floor.
- **Do not use masking or other types of adhesive tapes** on the surface coating, removal at a later stage may result in coating damage.
- Do not roll or slide heavy furniture or appliances across flooring without surface protection or lift trolley.
- Place drip pans or protective matting under pot plants and animal feeding or bedding areas to avoid moisture ingress.
- Importantly, make sure there is a minimum humidity of 35%- 50% in the room. Constant site variations above or below these limits may require the use of a humidifier. Good airflow and ventilation is required to avoid heat and cooling extremes. Long-term exposure may result in changes to the flooring surface. To resolve site specific circumstances please consult with your flooring Installer or retailer for advice.

Disclaimer: we have used its reasonable endeavors to ensure the accuracy and reliability of the information contained herein and, to the extent permitted by law, will not be liable for any inaccuracies, omissions or errors in this information nor for any actions taken in reliance on this information. Products must be installed in accordance with relevant installation recommendations and industry best practices.

Preference Floors (NSW)

ABN 40 117 801 037
32 Britton Street,
Smithfield NSW 2164
t +61 2 9738 1188
f +61 2 9738 1199
sales@preferencefloors.com.au

Preference Floors (VIC)

ABN 34 151 422 927
27-29 Zilla St ,
Dandenong South VIC 3175
t +61 3 9794 5111
f +61 3 9794 5133
vic@preferencefloors.com.au

Preference Floors (QLD)

ABN 81 169 158 990
6/268 Evans Road,
Salisbury QLD 4107
t +61 7 3875 1688
f +61 7 3875 1788
qld@preferencefloors.com.au

Preference Floors (SA)

ABN 63 600 454 215
47 Research Road,
Pooraka SA 5095
t +61 8 8262 2774
f +61 8 8359 4189
sa@preferencefloors.com.au

Preference Floors (WA)

ABN 25 625 850 455
30 King Street,
Bayswater WA 6053
t +61 8 9471 7785
f +61 8 9272 4906
wa@preferencefloors.com.au